


# Optional Output Connectors for CE Series Amplifiers Installation Guide (CEAS1/CEAS2)

## page 1 of 2



*CE Series Amplifier with Optional Output Connector Installed*

### TOOLS REQUIRED:

Torx #T-15 screwdriver

### INCLUDES:


- 2 - #8 x 1¼ in. screws
- CE optional output connector

**WARNING: CEAS1 AND CEAS2 OPTIONAL OUTPUT CONNECTORS MUST BE INSTALLED BY A QUALIFIED SERVICE CENTER.**

Follow the installation instructions provided on the next page to install your CE Optional Output Connector. Once installed, your CE amplifier will offer barrier block or 5-way binding post output connectors (depending on the kit ordered).


Note that installing the optional output connectors does NOT defeat the Neutrik® Speakon connectors on the back panel of the amplifier. If, at any time, you prefer to use the standard Neutrik® Speakon® output connectors, it is **not necessary to remove the optional output connector panel from the amplifier**. Instead, simply connect your speaker wires to the Speakon® output connectors instead of the optional output connectors.

### PART # CEAS1




*CE Series Amplifier Barrier Strip  
Output Connectors*

### PART # CEAS2



*CE Series Amplifier 5-Way Binding Post  
Output Connectors*

# Optional Output Connectors for CE Series Amplifiers Installation Guide (CEAS1/CEAS2). page 2 of 2



*CE Series Optional Output Connector Wire Locations*

## INSTRUCTIONS:

1. Turn down level controls.
2. Turn off amp.
3. Unplug power cord.
4. Remove the four T-15 torx-head screws from the top cover, and retain screws. Remove top cover.
5. Remove the two T-15 torx-head screws from the rectangular cover plate on the back panel, and retain screws. Remove cover plate and discard.
6. Install CEAS1/CEAS2 in back panel opening and affix with cover-plate screws.
7. Attach wires to main PWA as follows (refer to the illustration above):

**Red** wire to relay K100 "ON" terminal (location **A**).

**Orange** wire to relay K200 "ON" terminal (location **B**).

**Black** wire to WP7 lug (location **C**).

8. Reinstall top cover.
9. Connect wires to new output panel.
10. Plug in power cord.
11. Turn on amp.
12. Turn up the level controls to desired volume.